

Eco-Quilt is a very flexible, easy to install, multi-layer insulation that offers great thermal benefits



At only 15mm thick its open state EcoQuilt Expert compresses down to around 6mm. Making it The ideal insulation where space is vital.

With a Built in Vapour Control Layer Eco-Quilt Expert effectively stops any risk of condensation forming, as well as being a highly reflective insulation.





Save on Labour time. As there is no sawing or any Protective Clothing needed. Simply Cut EcoQuilt with a Sharp Blade or Scissors.

Order Online Today for Free
Next Working Day Delivery at:
Superquilt-Insulation.com

0114 323 0045

The Real Insulation Experts! sales@superquilt-insulation.com

Installation Guide And Data Information:

Keeps your loft space approximately 15 degrees cooler in the Summer



Built In Vapour Control Layer will help reduce condensation when fully taped and sealed

Great for Keeping
Conservatories Cooler In
the Summer and Warmer
In The Winter



General Fixing And Instructions:

- When fitting EcoQuilt in either a Loft, Wall, Floor, Garden Building or Conservatory it is vital that a 25mm air gap (batten) is present either side of the EcoQuilt. This will allow the material to Reflect and will also stop any Cold Bridging. You must also ensure that all overlaps, cuttings and the perimeter is fully taped and sealed using Thermaseal True Aluminium Foil Joining Tape.
 - EcoQuilt must be installed with a 50mm overlap, and fixed in place using 14mm staples at regular intervals.

Relaxed Thickness: Compressed Thickness:	15mm 6mm
Thermal Resistance:	Approx. 2.272
Weight:	400g m²
Length:	1500mm
Width:	10m
Components:	6 Layers of Foil and Wadding

Sales@SuperQuilt-Insulation.com / Technical@SuperQuilt-Insulation.com

Tel: 0114 323 0045 www.SuperQuilt-Insulation.com